



1. SEE EQUIPMENT PAD NOTES. 2. WHEN ANCHORAGE OF EQUIPMENT TO SLAB IS REQUIRED, USE SST WEDGE

ANCHORS SPECIFIED.

EQUIPMENT PAD





1. DIMENSIONS OF BASES, ANCHOR BOLTS, SIZES AND LOCATIONS TO SUIT EQUIPMENT SUPPLIED.


2. FOR GROUTED-IN DOWEL EMBEDMENT LENGTH, Le, REFER TO DETAIL / WB-S0454

3. ANCHOR BOLT EMBEDMENT DETAILS, PRESTRESSING, ETC AS REQUIRED BY EQUIPMENT MANUFACTURER.

WB-S0457

4. FOR ANCHOR BOLT DETAILS , SEE







NOTE:

1. VERIFY THE EXACT DIMENSION FOR RECESS IN FLOOR BASED ON SUPPLIER SELECTED.











- N.T.S.





STANDARD DETAILS