



Base course timbers shall be pinned with minimum of two (2) 19mm dia, rebar @ max. 1200mm O.C.
Timber above base course shall be securely spiked with min. two 12mm dia. x 250mm spikes @ max. 1200mm O.C.
Top course shall be screwed down using screws treated for ACQ use and sized to suit. Two screws at each end and every 600mm alternating sides along length.
Min. length of timbers to be 1200mm. Install longest lengths possible.