



**1** DRAINAGE SCUPPER PLAN VIEW  
 NTS

**GENERAL NOTES**

1. SCUPPER MUST BE PREFABRICATED. LAPS MUST BE FULLY SOLDERED.
2. SCUPPER MUST BE INSPECTED BY THE CONSULTANT PRIOR TO INSTALLATION.
3. INSTALL SCUPPER OVER THE BASE SHEET IN A FULL BED OF COMPATIBLE CEMENT IN THE SCUPPER OPENING.
4. FIELD VERIFY DIMENSIONS H & W.
5. SCUPPER MUST BE WRAPPED WITH PREFINISHED METAL, OR PAINTED TO MATCH.

RMIS ENGINEERING



389 MAXWELL CRESCENT  
 Regina, SK S4N 5X9  
 www.rmiseng.ca  
 Phone 306.352.4606  
 Fax 306.352.4607



FIRE HALL #23  
 C.13.MB.35-18.05.03

880 DALHOUSIE DRIVE  
 WINNIPEG, MB R3T 2Z9

CITY OF WINNIPEG

4TH FLOOR - 185 KING STREET  
 WINNIPEG, MB R3B 1J1

No.	DATE	DESCRIPTION

DESIGNED BY SMC 05/04/2018  
 DRAWN BY CJB 05/04/2018  
 REVIEWED BY SMC 05/04/2018

SCUPPER  
 DETAILS

**A 5.09**