

- 1. EXISTING REINFORCING STEEL SHALL BE REPLACED WITH NEW REINFORCING STEEL AS SHOWN.
- 2. IF JOINT REPAIR IS GREATER THAN 1000 WIDE ON EITHER SIDE OF THE JOINT, USE ADDITIONAL 12.7mm LONGITUDINAL PLAIN BARS AT 450 O.C. OR USE BAR MAT REF. SD-217...
- 3. WHERE BAR MAT IS USED. CUT OFF FINGER ENDS SO THE 150 GAP HAS NO FINGER ENDS.
- 4. ONLY TIE BARS AND DOWELS ARE REQUIRED FOR PLAIN DOWELLED PAVEMENTS.
- 5. INSTALL DOWELS AT PATCH ENDS, REF. SD-213B.

DIMENSIONS ARE IN MILLIMETRES

