
## **UPS-C1 INSTRUCTIONS**

## Startup Procedure


- 1. Turn MTS-C1 (Manual Transfer Switch) to the Line position.
- 2. Ensure that breaker BKR-C3 is closed and supplying power.
- 3. Close the disconnect switch, DS-UPS-C1 to supply power to the UPS.
- 4. Turn on the UPS battery circuit breaker, located at the rear of the UPS.
- 5. Wait for the -⊙→ indicator to illuminate on the UPS.
- 6. Turn MTS-C1 to the UPS position.
- 7. Verify that the -⊙→ indicator is off.

## Shutdown Procedure

- 1. Turn MTS-C1 (Manual Transfer Switch) from the UPS position to the Line position.
- 2. Press the  $\uparrow$  button on the front panel display and then press the  $\rightarrow$  button to select the *TURN UPS ON/OFF* menu.
- 3. Press the  $\downarrow$  button to select the *TURN UPS OFF* option; press the  $\leftarrow$  button.
- 4. Confirm the selection. Press and hold the ← button for three seconds, until the UPS stops beeping.
- 5. Turn off the UPS battery circuit breaker, located at the rear of the UPS.
- 6. Turn off the disconnect switch DS-UPS-C1.



-			
٠			
-			
	DRAWING NUMBER	REFERENCE DRAWINGS	



PALIN INC. Park Way 3, Canada R3P 0X7	ENGINEER'S SEAL PRELIMINARY	THE CITY OF WATER AND WASTE	
C. REIMER  D  FOR  ICTION	NOT TO BE USED FOR CONSTRUCTION	DEACON CHEMICAL FEED BUIL UPS UPGRADES OPERATING INSTRUCTIONS UPS-C1	
		CITY DRAWING NUMBER	SHEET
).dwg		1-0620C-E0005	00

SNC·LAVALIN

DESIGNED C. REIMER

DRAWN E. BOHNCKE

FILENAME: 1-0620C-E0005-001-00.dwg

**OF WINNIPEG**