



ADDENDUM NO. 1 BID OPPORTUNITY NO. 176-2005

2005 WATERMAIN RENEWALS – CONTRACT NO. 2

URGENT

**PLEASE FORWARD THIS DOCUMENT TO
WHOEVER IS IN POSSESSION OF THE BID
OPPORTUNITY**

ISSUED: April 29, 2005
BY: Stacy Cournoyer, EIT
TELEPHONE NO. (204) 986-2142

**THIS ADDENDUM SHALL BE INCORPORATED
INTO THE BID OPPORTUNITY AND SHALL
FORM A PART OF THE CONTRACT
DOCUMENTS**

Template Version: 20040128

Please note the following and attached changes, corrections, additions, deletions, information and/or instructions in connection with the Bid Opportunity, and be governed accordingly. Failure to acknowledge receipt of this Addendum in Paragraph 10 of Form A: Bid may render your Bid Submission non-responsive.

PART A – BID SUBMISSION

Pay item F.13 should be numbered as F.10.

PART E – SPECIFICATIONS

Add Clause E11 Asbestos Cement Pipe Samples and Bedding Samples:

E11. ASBESTOS CEMENT PIPE SAMPLES AND BEDDING SAMPLES

- E11.1 Take a bedding sample and remove existing asbestos cement (AC) pipe sample in accordance with the following at each location where the new watermain connects to an existing AC watermain.
 - E11.1.1 Select a minimum 1.5 metre length of AC pipe that is undamaged and has not been tapped for service connections as approved by the Contract Administrator.
 - E11.1.2 Expose the AC pipe down to the bedding using manual methods and equipment. Take precautions to not damage the AC pipe when exposing.
 - E11.1.3 Collect an uncontaminated bedding sample from as close as possible to the existing AC pipe before removing the AC pipe sample. Place the bedding sample into a plastic sample bag provided by the Contract Administrator.
 - E11.1.4 Indicate the top of the AC pipe as it is in place by making a readily visible scratch mark at one end of the sample.
 - E11.1.5 Cut the ends of the AC pipe sample as square as possible to the axis of the pipe.
 - E11.1.6 Follow safe work practices as outlined in D22 and all Workplace, Safety and Health regulations when cutting AC pipe.
 - E11.1.7 Rinse all dirt and cutting debris from the AC pipe sample before removing it from the excavation.
 - E11.1.8 Immediately wrap the AC pipe sample in at least 2 layers of minimum 6 mil thick clear polyethylene sheeting. While wrapping the pipe sample insert a warning label provided by the Contract Administrator inside the polyethylene sheeting such that it can be easily be read through the wrapping.

- E11.1.9 Deliver the AC pipe sample to a storage location as directed by the Contract Administrator within 24 hours of removing the sample from the excavation.
- E11.1.10 Offload the pipe sample as directed.
- E11.2 No separate measurement or payment shall be made for providing AC pipe samples and bedding samples.