

GENERAL NOTES


- FULL ROOF ASSEMBLY MAY NOT BE SHOWN. REFER TO DETAILS 1 & 2 ON A 5.01 FOR ROOF COMPOSITION

KEY NOTES



- LAY ASPHALTIC CORE BOARD ON ANGLE FLASHING AND MECHANICALLY ATTACH PANEL TO ANGLE FLASHING WITH 2" [51mm] PLATES AND FASTENERS @ 12" O.C. [305mm]
- MECHANICALLY ATTACH ANGLE FLASHING TO PARAPET/WALL/CURB WITH 2" [51mm] PLATES AND FASTENERS @ 12" O.C. [305mm]
- ENSURE 2" [51mm] MIN. LAP BETWEEN VAPOUR BARRIER AND BASE SHEET.

1 ROOF PROFILE
NTS

2 PERIMETER RESTRAINT
NTS



NOTE: METAL COUNTER FLASHING NOT SHOWN



3 MEMBRANE TERMINATION
NTS

4 BASE TIE IN
NTS

5 NEW WALL
NTS

RMIS ENGINEERING



389 MAXWELL CRESCENT
Regina, SK S4N 5X9
www.rmiseng.ca
Phone 306.352.4606
Fax 306.352.4607



FIRE HALL #23
C.13.MB.35-18.05.03

880 DALHOUSIE DRIVE
WINNIPEG, MB R3T 2Z9

CITY OF WINNIPEG

4TH FLOOR - 185 KING STREET
WINNIPEG, MB R3B 1J1

No.	DATE	DESCRIPTION

DESIGNED BY SMC 05/04/2018
DRAWN BY CJB 05/04/2018
REVIEWED BY SMC 05/04/2018

TYPICAL
DETAILS

A 5.01