

Cap Notes:


1. Cap shall be pre-drilled and screwed down using screws designed for fastening composites to ACQ treated wood and sized to suit.
2. Cap screws to extend into timber base min. 50 mm and to be countersunk into cap.
3. Two parallel screws every 600 mm O.C. along length and at ends.
4. Only use mitre joints for straight sections of cap.
5. Min. length of cap to be 1200 mm. Install longest lengths possible.

Drawing Title:


Double Timber Edging with Cap at accessible entrance

Drawing No:

SCD-651C



SECTION A



SECTION B

DIMENSIONS SHOWN ARE IN MILLIMETRES UNLESS OTHERWISE SPECIFIED

REVISION:

DATE: May. 24/19

SCALE: NTS

DRAWN BY: LL

The City of Winnipeg
 Planning, Property and Development Department
 Planning and Land Use Division
 Unit 15 - 30 Fort Street, Winnipeg, MB, R3C 4X5

